



# *Get started*

*All you need to know to get going.*

**SAMSUNG**

**Restore™**



**Welcome!**



*Sprint is committed to developing technologies that give you the ability to get what you want when you want it, faster than ever before. This booklet introduces you to the basics of getting started with Sprint and your new Samsung Restore.™ Just go to any basic function or Sprint feature that interests you. You'll see how easy it is to browse the Web, or send email or text messages. You can also download your favorite music, watch movies or Sprint TV, get turn-by-turn driving directions, choose ringers, screensavers, and much more. So jump right in. Because there's less waiting, and more doing, on the Now Network.™*

The services described in this guide may require a subscription to a service plan and/or may incur additional charges. Not all services will work on all devices. Coverage is not available everywhere.

**Important Privacy Message.** Sprint's policies often do not apply to third-party applications. Third-party applications may access your personal information or require Sprint to disclose your customer information to the third-party application provider. To find out how a third-party application will collect, access, use, or disclose your personal information, check the application provider's policies, which can usually be found on their website. If you aren't comfortable with the third-party application's policies, don't use the application.

©2010 Sprint. SPRINT and the logo are trademarks of Sprint. Samsung and Restore are trademarks of Samsung Electronics America, Inc. and/or its related entities. Other marks are property of their respective owners. Screen images simulated.



## Get Your Phone Ready

### ► Insert the Battery

- Insert the battery into the battery compartment and gently press down until it clicks into place.




### ► Charge the Battery

1. Plug the phone charger into an outlet.
2. Plug the other end of the charger into the phone's charger or accessory jack.

### ► Turn the Phone On

- Press  to turn the phone on.

### ► Switch to Spanish Menus (optional)

1. Highlight  and press  > **Settings** > **Others** > **Language**.
2. Highlight **Español** and press .

## Activate Your Phone

### ► Activate Your Phone

- If you purchased your phone at a Sprint Store, it is probably activated and ready to use.
- If you received your phone in the mail, and it is a new Sprint account or a new phone number, your phone is designed to activate automatically when you first turn it on. To confirm your activation, make a phone call.
- If you received your phone in the mail and it is going to be activated on an existing number (you're swapping phones), go to [sprint.com/activate](http://sprint.com/activate) and follow the instructions.

When you have finished, make a phone call to confirm your activation. If your phone is still not activated or you do not have access to the Internet, contact Sprint Customer Service at **1-888-211-4727** for assistance.







## Sprint One Click




### ► Introducing Sprint One Click

Sprint One Click brings all your favorite features to your fingertips on your Samsung Restore.™

This easy-to-use design lets you access features such as **Messaging** , **GPS Navigation** , **Google** , and the **Internet**  all without having to leave the main screen.

### ► Get to Know the Main Screen

• **Carousel** – The bottom row of tiles, or icons, on your main screen. The carousel gives you instant access to your favorite features.


To select a tile, scroll with the optical joystick right or left to move the carousel. The center tile is the selected tile. (The **Home** tile  is selected in the illustration on the left, displaying the Home screen.)

To highlight an option above a tile, scroll with the optical joystick up or down to select it.

### ► Personalize Your Carousel

Your phone's carousel holds up to 15 tiles. Add, remove, and rearrange tiles as often as you like. For more information, see Section 2B: Navigating the Main Screen in the User Guide online at [sprint.com/restoresupport](http://sprint.com/restoresupport).


### ► Learn More

Use the built-in Tutorial to learn all you need to know about Sprint One Click. Highlight  and press **OPTIONS** (left softkey) > **Tutorial**.

## Voicemail

### ► Set Up Your Voicemail

All unanswered calls are automatically transferred to your voicemail, even if your phone is in use or turned off. You should set up your voicemail and personal greeting as soon as your phone is activated:

1. Press and hold  and follow the system prompts to create your passcode and record your name and greeting.




#### Voicemail Passcode

(do not share): \_\_\_\_\_

Sprint strongly recommends setting a voicemail passcode. Without a passcode, anyone who has access to your phone can access your messages and place outbound calls through your wireless account.

### ► Retrieve Your Voicemail

From your phone:

- To use One Touch Message Access, press and hold .
- To use the phone's menu, highlight  and press  > **Messages** > **Voicemail** > **Call Voicemail**.

From any other phone:

1. Dial your wireless phone number.
2. When your voicemail answers, press **\***.
3. Enter your passcode.



## Make Your First Call

### ► Make Your First Phone Call

1. Enter a phone number using your keypad.  
(If you make a mistake while dialing, press **⏮** to erase.)
2. Press **☎**.
3. When you're finished, press **⏹**.



## Contacts

### ► Save a Phone Number

1. Enter a phone number and press **OPTIONS** (right softkey) > **Save Contact**.
2. Highlight **New Entry** or **Existing Entry** and press **⏮**.
3. For **New Entry**, select a category for the number (such as **Mobile**, **Home**, **Work**, **Pager**, **Fax**, or **Other**), and then enter a name for the entry. For **Existing Entry**, select an existing entry, and then select a phone type and press **⏮**.
4. Press **DONE** (left softkey).

### ► Retrieve a Phone Number

1. Press **CONTACTS** (right softkey).
2. Use your optical joystick to scroll through the entries, or use your keypad or Qwerty keyboard to enter the first few letters of the contact entry.
3. To display an entry, highlight it and press **⏮**. To call the entry's default phone number, highlight it and press **☎**.

## Messaging

*Stay connected. Any way you want.*

*Keep in touch your way using text and picture messaging, or email. Easy access to AOL, Hotmail, AIM Mail, Yahoo® Mail, and Gmail.*



### ► Send Text (SMS) Messages

1. Highlight **⏮** and press **⏮** > **Messages** > **Send Message**.
2. Select a recipient from recent messages, select **Go to Contacts** to select a recipient from your contacts, or press **NEW ADDR** (right softkey) to enter a phone number or email address by hand.
3. Enter a wireless phone number or email address. If prompted, press **CONTINUE** (left softkey).

4. Use your keypad or Qwerty keyboard to enter a message or press **OPTIONS** > (right softkey) to choose from preset messages or Smileys.
5. Press **SEND** (left softkey).

### ► Send Picture (MMS) Messages

1. Follow steps 1 - 3 for sending a text message.
2. Select **<Add attachments>** > **My album**, **Take new picture**, or **Take new video**.
3. Use your keypad or Qwerty keyboard to enter a message and press **SEND** (left softkey).

### ► Set up Email

1. Highlight **⏮** and press **⏮** > **Messages** > **Email**.
2. Select **Yahoo! Mail**, **Hotmail**, **Gmail**, **AOL Mail**, **Work**, or **More...** and follow the onscreen instructions.

## Pictures & Videos

*Live the moment. Then share it.*

*Capture and instantly send your moments in digital pictures and video clips.*



### ► Take a Picture

1. Press and hold the side camera button to activate the phone's camera.
2. Using your display as a viewfinder, aim the camera lens at your subject, and press **■** or the camera button.
3. Press the camera button to return to camera mode, or press **OPTIONS** (right softkey) to explore other options, including sending the picture.

### ► Record a Video

1. Highlight **■** and press **■** > **Photos & Videos** > **Camcorder** to activate video mode.
2. Select **Video Mail** or **Long Video**.
3. Using the phone's display screen as a viewfinder, aim the lens at your subject, and press **■** or **■** to begin recording.
4. Press **■** or **■** or to stop recording.
5. Press **OPTIONS** (right softkey) to explore menu options including sending the video.

### ► Share

1. Highlight **■** and and press **■** > **Photos & Videos** > **My Photos & Videos** > **My Albums** > **In Phone** or **Memory Card**.
2. Highlight pictures or videos to send, then press **SEND** (left softkey).
3. Select **Contact**, **Bluetooth** or **New Place...**
4. Follow the onscreen instructions to send pictures and videos.

## Ringers & Screensavers

*Make your phone your own.*

*Personalize your phone with a huge selection of ringers and screensavers. Know exactly who's calling by matching contacts with unique ring tones.*



### ► Play/Use

1. Highlight **■** and press **■** > **My Stuff** > **[Ringers or Screen Savers]** and then select **Get New**.
2. Select an item and press **■**.

## Games

*Don't wait. Play.*

*Thousands of downloadable games for when your world is on pause. Find your favorite or try a new one from the free demo section.*



### ► Download





1. Highlight **■** and press **■** > **Web** > **Downloads** > **Games**.
2. Select an item and press **Go** (left softkey) to view the summary page, and then select **Buy**.
3. Pick an option to assign the downloaded item (or to start the game or application).

## Web

*Online. On your phone.*

*Find sports scores, news, and weather. Shop online. On-the-go access lets you browse full-color versions of your favorite websites.*

### ► Go Online

1. Highlight  and press  > **Web**.  
– or –  
Select .
2. From the Sprint home page, select categories, navigate to websites, read blogs, download content, and more.
  - To go to a category, highlight it and press .
  - For more options, press the right softkey from any page.







## Sprint TV, Movies & Radio

*Watch what you like. Where you like.*

*Live TV and video on demand. Complete episodes and clips of your favorite primetime shows and movies. Over 50 channels of news, entertainment, weather, sports, and streaming music.*



### ► Watch

1. Highlight  and press  > **Entertainment > Sprint TV**.
2. Select a channel or category and press .  
If prompted, select **Preview** or select **Subscribe** to purchase access.
3. Select an item and press  to play it.






\* Coverage not available everywhere. Content and lineup subject to change. Select channels also available for casual usage. Go to [sprint.com/tvguide](http://sprint.com/tvguide) for more information.


## GPS Navigation

*All the right turns. And left ones.*

*Sprint Navigation lets you see and hear turn-by-turn directions to a known address, or find nearby restaurants, stores, banks, or gas stations. Get information about traffic and alternate routes.*

### ► Navigate

1. Highlight  and press  > **Maps** > **Sprint Navigation**.  
– or –  
Select .
2. Follow the onscreen instructions to access, launch and use.















## Manage Your Account

### ► Online: [www.sprint.com](http://www.sprint.com)

- make a payment, see your bills, enroll in online billing
- check minute usage and account balance
- see or modify the details of your Sprint service plan
- get detailed instructions and download content

### ► From Your Sprint Phone

- Press    to check minute usage and account balance
- Press    to make a payment
- Press    to access a summary of your Sprint service plan or get answers to other questions

- Press    to add a new line of service, upgrade your phone, purchase accessories, or access other account services

### ► From Any Other Phone

- Sprint Customer Service:  
Dial **1-888-211-4727**
- Business Customer Service:  
Dial **1-800-927-2199**



## Helpful Sprint Information

### ► Total Equipment Protection

*The protection you need so you can be worry free*

Should anything happen to your phone, you'll have a worry-free way to ensure that you get connected again soon.

#### • Coverage includes:

Loss, theft, routine maintenance, physical or liquid damage, mechanical or electrical problems, failure from normal wear and tear.

#### • For more information:

See the Total Equipment Protection brochure available at any participating retail location or go to [sprint.com/tep](http://sprint.com/tep) for more details. To enroll within 30 days of activation, call **1-800-584-3666**.

Total Equipment Protection is a service provided by Asurion Protection Services, LLC, Continental Casualty Company's (a CNA company) licensed agent for the customers of Sprint.

### ► Sprint 411

Dial 411 for nationwide listings, movie show times, restaurant reservations, driving directions and more. Spanish-speaking operators are available. See [sprint.com](http://sprint.com) for pricing and more details.

## Resources

### ► For Your Phone

- This *Get Started Guide* to get you up and running.
- **Web** – Go to [sprint.com/restoresupport](http://sprint.com/restoresupport) to download the latest version of the *User Guide*, and to access troubleshooting and other resources.

### ► For the Environment

Recycle your old phone safely and conveniently using the addressed recycling envelope packaged with your new phone. Visit [sprint.com/recycle](http://sprint.com/recycle) for more details.

## sprint.com/begin

- Visit [sprint.com/begin](http://sprint.com/begin) to discover all you can do with your phone and Sprint service. Explore all your options, find ways to personalize your experience, even vote for your favorite features. It's a whole new beginning.

## Survey

### ► Please tell us what you think about your new phone

We are interested in your initial impressions of this new Sprint phone. Within two weeks of your phone purchase, please go to the website <http://labs.sprint.com/sprintphonesurvey> to complete a brief survey. Your feedback will help us provide the wireless features and services you want most.

**Thank you for choosing Sprint.**



## product registration

Visit

[samsungmobileusa.com/register](http://samsungmobileusa.com/register)

to register your Samsung purchase.

Stay informed about current promotions, events, and special offers on related products.



**"number one in brand loyalty eight years in a row"**

Samsung mobile phones have been rated number one in brand loyalty by consumers eight years in a row, according to Brand Keys, a leading independent authority on brand loyalty.



