



**Centro™**  
SMART DEVICE

## Tips and Tricks for your Palm® Centro™ smart device

Sprint  ahead



## Phone

Dial from Contacts	Select <b>Contacts</b> . Type part of the name to narrow your search. Use the <b>5-way</b> to select the number.
Map a Contact's address	Highlight a contact then select <b>Map</b> .
Speed Dial	Use the <b>5-way</b> to select a Contacts Favorite.
Create new Favorite	Select a blank favorite button and enter the info.
Access voicemail	Press and hold <b>1</b> .
Add photo as wallpaper	Press <b>Menu</b> and select <b>Options &gt; Phone Display Options</b> .
Answer a call with text	Select <b>Ignore with Text</b> when a call comes in.


## Google Maps

Find an airport	Press <b>Menu</b> then <b>Find Location</b> .
Find a business	Press <b>Menu</b> then <b>Find Nearby Business</b> . Enter a category and location; "pizza in Chicago."
Call a business	Type the flag number (or tap it) and select <b>Dial</b> .
Show traffic speeds	Press <b>#</b> .
Next direction	Press <b>Space</b> .
Previous direction	Press <b>Backspace</b> .
Return to route	Press <b>Return</b> .

## Messaging

- Type predefined phrase    Select 
- Attach photo or video    Select **Add media...**
- Insert "smiley"    Select  to see your choices.
- Use standard short codes    For example, text "movies [your zip]" To: 92466 (Yahoo! shortcode) to see a list of local movies.

## Email

- Check multiple email accounts    Press **Option + Messaging** again to see the next account.
- Attach file    Select attachment icon 
- Use Inbox shortcuts    Highlight a message. Press **Right** on the **5-way** to quickly access these commands:
- |              |
|--------------|
| Delete       |
| Mark Read    |
| Mark Unread  |
| Forward...   |
| Reply...     |
| Reply All... |
| Move To      |

## Web

- View previous page    Press **Backspace**.
- Save image    Tap and hold the image.
- Dial number on page    Use **5-way** (or tap) to select number.
- Open link on page    Use **5-way** (or tap) to select link.
- Jump to address bar    Press **Space**.
- Access title bar icons    Press **Space**, then **Up** on the **5-way**.



## Customizing hardware buttons


Pressing a **Quick Button** instantly wakes up your Palm® Centro™ smart device and opens an application:



Pressing **Option** before pressing a **Quick Button** opens these applications:



You can assign other applications to these buttons with the **Buttons** panel inside the **Prefs** application.



All screen images are simulated.

© 2007 Palm, Inc. All rights reserved. Palm, Centro, and the Palm and Centro logos are among the trademarks or registered trademarks owned by or licensed to Palm, Inc. All other brand and product names are or may be trademarks of, and are used to identify products or services of, their respective owners.

## Hidden gems

### Phone

- Press **Phone** then **Talk** to show a list of recent calls

### Talk

- Press **Phone** then hold **Talk** to redial your last call

### Calendar

- Press again to see next view: Day, Week, Month and Agenda

### Option

- Press before other keys to use their secondary function
- Press **Option** twice to lock it

### Ringer switch

- Slide to **Sound Off** to silence all sounds



### Shift/Find

- **Option + Shift** to search; search results include links to Google map features
- Press **Shift** twice to lock it



### Applications

- Press again to show next category of apps
- Press & hold at any time to show list of recent apps

### Power/End

- Press & hold to turn wireless services on or off
- Press to ignore incoming call and send it to voicemail

### P


- **Option + P** adjusts brightness

### Menu

- **Option + Menu** dims screen
- Press for menu shortcut. For example, **Menu + C** is **Copy**

### Alt

- Press after other buttons to type alternate characters
- Press by itself to open a palette of common symbols:



### Space

- Start/Stop music in Pocket Tunes Deluxe™
- Start/Stop videos in Pics&Videos