



*Get started.*

*All you need to know to get going.*

**SANYO** SCP-2700



# Welcome

*Sprint is committed to developing technologies that give you the ability to get what you want when you want it, faster than ever before. This booklet introduces you to the basics of getting started with Sprint and your new SCP-2700 by SANYO®.*

**Only on the Now Network™.**

# Get Your Phone Ready

## > Insert the Battery

1. Insert the battery into the battery compartment, making sure that the connectors align, and gently press down until the battery clicks into place.
2. Replace the battery cover.



## > Charge the Battery

1. Plug the phone charger into a wall outlet.
2. Plug the other end of the charger into the micro-USB connector located on the lower left side of the phone.

## > Turn the Phone On

- Press and hold  to turn the phone on.

## > Switch to Spanish Menus *(optional)*

1. Press  > **Settings** > **Display** > **Language**.
2. Highlight **Español** and press .






## Activate Your Phone

- If you purchased your phone at a Sprint Store, it is probably activated and ready to use.
- If you received your phone in the mail, and it is a new Sprint account or a new line of service, it is designed to activate automatically. To confirm your activation, make a phone call.
- If you received your phone in the mail and you are activating a new phone for an existing number on your account, you will need to go online to activate the number on your new phone.
  - From your computer's Web browser, go to **sprint.com/activate** and complete the onscreen instructions to activate your phone.

When you have finished, make a phone call to confirm your activation. If your phone is still not activated or you do not have access to the Internet, contact Sprint Customer Service at **1-888-211-4727** for assistance.

# Make Your First Call


## **Make Your First Phone Call**

1. Enter a phone number using your keyboard. (If you make a mistake while dialing, press  to erase.)
2. Press .
3. When you're finished, press .

# *Vicemail*



## > **Set Up Your Voicemail**

All unanswered calls are automatically transferred to your voicemail, even if your phone is in use or turned off. You should set up your voicemail and personal greeting as soon as your phone is activated:

1. Press and hold .
2. Follow the system prompts to create your passcode and record your name and greeting.

## > **Retrieve Your Voicemail**

From your phone:

- To use One Touch Message Access, press and hold .
- To use the phone's menu, press **MESSAGES** (left softkey) > **Voicemail** and then press .

From any other phone:



1. Dial your wireless phone number.
2. When your voicemail answers, press **\***.
3. Enter your passcode.

# Contacts

## > Save a Phone Number


1. Enter a phone number and press **OPTIONS** (right softkey) > **Save**.
2. Select **New Entry** or **Existing Entry**.
3. For **New Entry**, select a type for the number (such as **Mobile, Home, or Work**), enter a name, and add other information as needed.  
For **Existing Entry**, select the entry, select a type, and add other information.
4. Press **DONE** (left softkey).

## > Retrieve a Phone Number






1. Press **CONTACTS** (right softkey).
2. Use your navigation key to scroll through the entries, or use your keyboard to enter the first few letters of the contact entry.
3. To display an entry, highlight it and press . To call the entry's default phone number, highlight it and press .

# Messaging and Pictures

## > Send a Text Message

1. Press .
2. Select **Go To Contacts** to select a Contacts entry, or press **MULTIPLE** (left softkey) to select multiple recipients or **NEW ADDRESS** (right softkey) to enter a phone number or email address.
3. Use your keyboard to enter a message or press **OPTIONS** (right softkey) to select additional options.
4. Press **SEND** (left softkey).

## > Take a Picture













1. Press and hold  (the camera button on the side of your phone) to activate the phone's camera.
2. Using your display as a viewfinder, aim the camera lens at your subject, and press , , or **CAPTURE** (left softkey).
3. Press  or  to return to camera mode, or press **OPTIONS** (right softkey) to explore other options, including sending the picture using Sprint Picture Mail.

# Manage Your Account

## > **Online: [sprint.com](http://sprint.com)**

- make a payment, see your bills, enroll in online billing
- check minute usage and account balance
- see or modify the details of your Sprint service plan
- get detailed instructions and download content

## > **From Your Sprint Phone**

- press     to check minute usage and account balance
- press     to make a payment
- press     to access a summary of your Sprint service plan or get answers to other questions

## > **From Any Other Phone**

- Sprint Customer Service: Dial 1-888-211-4727
- Business Customer Service: Dial 1-800-927-2199

# Helpful Sprint Information

## **Recycle Your Old Phone**

Get an account credit or help Sprint support Internet safety for kids by recycling your old phone through Sprint wireless recycling programs. Visit [sprint.com/recycle](http://sprint.com/recycle) for details.

## **Total Equipment Protection**

With Total Equipment Protection, your phone will be protected against loss, theft, physical, and liquid damage as well as covered for mechanical and electrical failure, routine maintenance, and failure from normal wear and tear. Enroll when you activate or upgrade your phone or smart device. You have up to 30 days after activation or upgrade to enroll, so don't delay.\*

\*Please see the Total Equipment Protection brochure available at any participating retail location or visit [sprint.com](http://sprint.com) for complete terms and conditions of coverage including applicable charges and deductible(s). Terms and conditions are subject to change. May not be available in all states. Eligibility varies by device. Claims may be fulfilled with new or refurbished equipment.

## **Sprint 411**

Dial 411 for nationwide listings, movie show times, restaurant reservations, driving directions and more. Spanish-speaking operators are available. See [sprint.com](http://sprint.com) for pricing and details.

# Thank you.

*This is only the beginning of what you can do with your SCP-2700 by Sanyo® and Sprint. There are many additional resources at your fingertips.*

- *The **User Guide** gives additional details on how to use your phone, and is also available online in Spanish.*
- ***sprint.com** provides all the information on your plan and available services as well as downloadable content.*
- *Visit [sprint.com](http://sprint.com) and click **Accessories** or call the accessories hotline, **1-866-866-7509**, to outfit your phone.*

