



Worldwide Traveling Tips

BlackBerry® Tour™ 9630 smartphone

Before You Travel

Activate your BlackBerry Tour with voice and/or data service:

Voice and/or data service must be enabled prior to travel. Before traveling be sure that you have placed and received a call and accessed data services, if needed while traveling. Service must first work on the Nationwide Sprint Network before it will work while roaming.

Enable your BlackBerry Tour international wireless voice and/or data service:

1. Chat with or email an international support rep by visiting sprint.com/international and clicking **Chat with us** or **Email us** or place a call to 1-888-226-7212, option 2
2. Request that your international services be enabled
3. Specify that international voice and/or international data be enabled

Check coverage, rates and features available for the location(s) you will visit:

1. Visit sprint.com/sww
2. Select a country and click **Search**
3. View features available in city list. Scroll through or select first letter of city name
4. The BlackBerry Tour will operate where "Advanced Worldmode" displays

Identify international calling codes for location(s) you will visit and location(s) you plan to call:

To make an international call while traveling internationally you will need:

- > The international access code of the country you are traveling in
- > The country code for the country you are calling to
- > The phone number you are calling

International access codes and country codes are available on sprint.com/sww or access travel guide for the country you will be visiting:

1. From sprint.com/support, select **BlackBerry Tour** from device list
2. Select **Travel Tips** link
3. Select country you will be visiting for specific dialing and service details

Set voicemail passcode:

You must know your voicemail passcode to access voicemail outside of the U.S. If you do not know your passcode, you may reset it at

sprint.com:

1. Log in to **My Sprint**
2. Select **Settings & Passwords** at the bottom right-hand side of the page
3. Click **Voicemail Passcode**
4. Enter new passcode, re-enter and click **Submit**

Texting:

Your device will automatically be able to receive texts when traveling internationally. All texts received while traveling internationally are billed the same rate for the country you are traveling in, regardless of where the text is sent from. Check sprint.com/sww for texting rates or check sprint.com/support (select your device) to prevent your device from receiving texts. You will need to enable your device to send texts while roaming on GSM networks. Once the steps below

are completed you will be able to send texts on any available network while traveling internationally; this process only needs to be completed once.

To enable device for sending texts on GSM networks:

1. Tap **Start** > **Settings** > **Menu** > **Phone Network Mode**
2. From the Mode of operation drop-down list select **GSM**
3. Tap **OK**
4. Go to **Settings** > **Communications** > **Phone**
5. Select **GSM/UMTS** tab, then select **Voice Mail** and **Text Messages**
6. Press **Get Settings**
7. Type +12819659999 in the **Text Messages Service Center box**, then select **OK** to finish

Sending a text while traveling is identical to sending a text from home.

1. When sending a text to a U.S.-based number or to any number within the North American Numbering Plan* simply enter the 10-digit number
2. When sending a text to a non-U.S.-based number, enter 011 then the country code and number

*North American Numbering Plan Countries: Anguilla, Antigua, Bahamas, Barbados, Bermuda, British Virgin Islands, Canada, Cayman Islands, Dominica, Dominican Republic, Grenada, Jamaica, Montserrat, St. Kitts and Nevis, St. Lucia, St. Vincent and the Grenadines, Trinidad and Tobago, Turks and Caicos Islands, and U.S. Territories (Puerto Rico, U.S. Virgin Islands and Guam).

While Traveling Abroad

General Instructions for Use

Your BlackBerry Tour is designed to enter global roaming mode automatically when you enable your Sprint Worldwide service, meaning that it should automatically connect to an appropriate CDMA network or GSM network when you travel.

Select GSM Mode:

Upon arriving in a country with CDMA voice and GSM voice and data coverage, change the settings to GSM mode to be able to access data services.

1. Press menu key, scroll to Options and click trackball
2. Scroll to Mobile Network and click trackball
3. Scroll to Network Technology and click the trackball
4. Highlight GSM/UMTS and click the trackball
 - GSM/UMTS to allow connections to GSM networks only
 - 1XEV to allow connections to CDMA networks only
 - Global to allow connections to available CDMA or GSM networks
5. Press End key
6. Change device back to Global mode when traveling to another destination or when returning home

Manually Selecting a Network:

When using the device in GSM/UMTS Mode it will automatically search for service; however, it may be necessary to manually select a different carrier to access data.

1. Press menu key, scroll to Options and click trackball
2. Scroll to Mobile Network and click trackball
3. Scroll to Network Selection Mode click the trackball
4. Highlight **Manual** and click the trackball. The device will search and list the available networks
5. Select the network that supports Sprint International GSM Data Roaming. (Check sprint.com/sww for a list of which carriers in which countries support GSM Data)

Making and Receiving Calls:

Local calls: Local calling procedures vary by country. Please use the same procedures to dial locally from your BlackBerry Tour as you would from a wireline phone in that country.

International calls: International access code, country code, area code, phone number. International dialing is simplified with plus code dialing when on GSM networks.

Example: Calling Manhattan, N.Y. from London:
+ 1 212 555 2121

When in CDMA Mode - Dial international access code for the country you are in then the country code you are calling and the phone number.

Example: Calling Manhattan, N.Y. from Mexico:
00 1 212 555 2121

Receiving Calls: Simply power on your phone. Your callers do not need to dial anything different and they will not pay extra to reach you. Roaming rates apply to you only.

Accessing Voicemail:

1. Dial the international access code (or if in GSM mode, press and hold the 0 [zero] key until a + appears on your phone display)
2. Enter 1, then your Sprint number
3. When voicemail answers, press (star) and enter the voicemail passcode followed by (pound)

Sprint Worldwide Customer Support

Access a dedicated team of Sprint specialists via chat or email by visiting sprint.com/international and clicking **Chat with us** or **Email us** or place a call to one of the following numbers:

- > From your Sprint phone (this call will be free):
Dial international access code, then 1, then 817-698-4199, option 3
- > From a wireline phone: Call 1-817-698-4199, option 3 (access and connection fees may apply in addition to long-distance costs)
- > Toll-free numbers are also available from several countries. The toll-free* numbers below can be used to contact Sprint in the following countries:
 - Most Caribbean Islands . . . 1-888-226-7212
 - France . . . 0800-903200
 - Germany . . . 0800-180-0951
 - Italy . . . 800-787-986
 - Mexico . . . 001-877-294-9003
 - United Kingdom . . . 0808-234-6616

** This toll-free service is available at ordinary wireline and some public pay phones. This service does not cover any hotel access charges.*

Travel Checklist

General – Before Traveling

1. Call, chat with or email a Sprint Worldwide Customer Care rep to enable phone and SIM card for international wireless services. If your phone number, device or SIM card changes, call Customer Care to enable your new number, device or SIM
2. Get list of country dialing codes
3. Set voicemail passcode

When Traveling to Another Country

1. Power phone on; the device should find and register with an available network
2. To access data services, ensure you are on the carrier network that supports data. You may need to manually switch from 1XEV to GSM/UMTS to access data
3. While in GSM/UMTS Mode, your device will automatically search for data carriers first. However, if data is not available on that carrier, it may be necessary to manually select a different carrier. Follow directions for “Manually Selecting a Network”

To view a list of data networks, go to sprint.com/international, click **Traveling Internationally with a Sprint Phone** and then click **GSM Roaming Partners** on the right.

Inserting/Swapping SIM Cards

Your Sprint SIM card should be preinstalled. If you get a “No SIM card found” error message or if you need to reinstall or swap your SIM card, please follow the instructions below to place the SIM card properly in your phone.

1. Press the battery cover release button, slide off the battery cover and remove the battery
2. Hold the SIM card so that the metal contacts on the SIM card face down and the cutoff corner points toward the lower-right corner of the BlackBerry device

